

Running a little late getting home? Relax! With Restart TV, you can go back to the start of a favorite show that's already begun – just press the green button. Do the same if you see a movie playing that you want to watch in its entirety.

Restart TV is a FREE feature

- Available on virtually all channels as indicated by the green Restart icon
- Gives you flexibility with your TV program viewing and schedule
- Restart a show already airing by the press of one button
- Offers the convenience of pause or rewind a Restart TV program while in session
- Programs can be restarted multiple times during the live time frame
- Programs can be recorded on DVR after program has been restarted

Restart TV - Using the Program Guide and Browser Bar

- Restart TV Programming is indicated by the Green and White Restart icon next to the channel
- Highlight the program you wish to watch and press the GREEN button on your remote to Restart the program from the beginning

Restart TV - Using the What's Hot App

- All Restart TV programming in the What's Hot App is indicated by the green and white Restart icon next to the channel information below the program title
- Highlight the program you wish to watch and press the GREEN button on your remote to tune to the program and watch it from the beginning

Pause Live TV - Using DVR Functions On Remote

 All set top boxes will now pause live TV. To pause live TV at any time push the pause button II on your remote located with the DVR functions. To undo pause push start arrow or Live button on your remote.